



DUO

COMPONENTRY LOCATION

Similar to other appliances, a spa pool requires regular maintenance and servicing to ensure its optimal performance. This guide shows you the location of key components within the spa pool to help simplify the servicing and inspection process.



Click here to view:
Cabinet Panels Removal Video



Inspect Every : 3-4 Months



Controller & Heater

The brain and heating element.
Located behind **FRONT** panels



Inspect Every : 3-4 Months



2-Speed Pump

The 2-speed pump controls filtration and hydrotherapy.
Located behind **RIGHT** panels



Inspect Every : 3-4 Months



Ozone Machine

Generates Ozone to assist sanitisation.
Located behind **FRONT** panels



Drain Every : 3-4 Months



Drain Valve

Attach a hose, twist and turn to release the flow of water
Located behind **RIGHT** panels

NZ

www.alpinespas.co.nz
0800 99 33 88
service@alpinespas.co.nz

AU

www.alpinespas.com.au
1800 99 33 88
service@alpinespas.com.au