



YUKON

COMPONENTRY LOCATION

Similar to other appliances, a spa pool requires regular maintenance and servicing to ensure its optimal performance. This guide shows you the location of key components within the spa pool to help simplify the servicing and inspection process.



Inspect Every : 3-4 Months



Circulation Pump

Cycles water through the filters and heating element.
Located behind **FRONT** panels



Inspect Every : 3-4 Months



Controller & Heater

The brain and heating element.
Located behind **FRONT** panels



Inspect Every : 3-4 Months



Ozone Machine

Generates Ozone to assist sanitisation.
Located behind **FRONT** panels



Inspect Every : 3-4 Months



Jet Pump

High-speed pump which powers hydrotherapy.
Located behind **FRONT** panels



Drain Every : 3-4 Months



Drain Valve

Attach a hose, twist and turn to release the flow of water
Located behind **LEFT** panels

NZ

www.alpinespas.co.nz
0800 99 33 88
service@alpinespas.co.nz

AU

www.alpinespas.com.au
1800 99 33 88
service@alpinespas.com.au